CFMOTO

ACCESSORY SETUP INSTRUCTION

FRONT WINDSHIELD ASSY -- PN 5BWV-805100-5000
VALID FOR: 2023 ZFORCE 800

BEFORE YOU BEGIN: Read and understand the instructions before starting any work. Make sure that all parts are ready and that you have all the tools required for assembly.

NOTE: CFMOTO shall not be liable for any damage caused by incorrect assembly. CFMOTO recommends that all original accessories be assembled by an authorized CFMOTO dealer.

Before assembly, park the vehicle on a flat surface, put the transmission gear into Park (P) and turn off the key switch.

MEANING OF SYMBOLS

i - Indicates information with more details or tips.

**!** - Indicates information of warning or danger.

PARTS LIST:

ITEM	PART NAME	PART NUMBER	QTY.	REMARK
1	FRONT WINDSHIELD ASSY	5BWV-805100-5000	1	
2	FRONT WINDSHIELD	5BWV-805101-5000	1	
3	CLAMP	5ASV-804100-6000	4	Picture is for structure reference only.
4	DAMPING RUBBER STRAP	5BWV-805100-5000-20	1	
5	THREAD LOCKER	5BWV-805100-5000-23	1	
6	T25 WRENCH	5BWV-805100-5000-24	1	

TOOL LIST:

| ITEM	DESCRIPTION	QTY.	REMARK
1	PROTECTIVE GLOVES	1	Recommended tools.
2	4mm ALLEN WRENCH	1	

ASSEMBLY and INSTALLATION

// Remove gaskets (B) and screws (A) from the clamps (3), then install the clamps (3) onto the front windshield (2) with the gaskets (B) and screws (A) in the order shown. *Do not fully tighten screws at this time*.

ℹ️ Remove protective film from the windshield before assembly. Apply thread locker (5) to the screws.

Tilt the windshield assembly (2) and position it between the top roof and the top bar assembly.

// Determine the clamp positions, then secure clamps (3) on each side as shown. Hand-tighten the clamp screws sufficiently, using care not to over-tighten.

The front windshield assembly is assembled.